
FIG. 1








FIG. 3



## FIG. 4



(TO NEXT STEP TO EXECUTE NEXT STATEMENT)



START


DESCRIBE FOLLOWING SETTINGS IN EACH STATEMENT OF BASIC (OUT STATEMENT)

- 1 EXECUTE/CANCEL AUTOMATIC OPTIMIZATION FOR FLASH MEMORY IN RELATION TO EXECUTION OF SPECIFIC STATEMENT
- ② EARLIER/LATER THAN EXECUTION OF SPECIFIC STATEMENT IN THE CASE OF EXECUTING OPTIMIZATION
- ③ OPTIMIZATION SIZE IN THE CASE OF EXECUTING OPTIMIZATION

**END** 

S31







START

DESCRIBE FOLLOWING SETTINGS (OUT STATEMENT)

1 EXECUTE/CANCEL AUTOMATIC OPTIMIZATION FOR FLASH MEMORY AT DESIGNATED DATE/TIME

- 2 DETAILED DATE/TIME FOR OPTIMIZATION IN THE CASE OF EXECUTING OPTIMIZATION
- ③ OPTIMIZATION SIZE IN THE CASE OF EXECUTING OPTIMIZATION

**END** 

1<sub><</sub>S51